

1. Download App “GEYER Smart” from Google Play Store or App Store or scan the QR code.**2. Connect the smoke alarm to the cell phone.**

After downloading the app, register and become a member.

Follow the app wizard to add the device. Make sure your phone's Bluetooth and location are turned on and you are connected to your home's Wifi (on 2.4 GHZ Wifi frequency **only**)

The steps will be the following:

- Press the "+" top right corner (**Picture 1**)
 - Press "Add device"
 - Press the smoke detector button twice, the smoke detectors start to flash green quickly
- The smoke detector to add appears (**Picture 2**)
 - Press "Add"
- Enter your Wifi name and password (**Picture 3**)
- Wait until the loading circle in the app is full (**Picture 4**)
- Press "Done" when it turns green to add to the app (**Picture 5**)


Note:

1. After connection, when we press the “TEST” button of the smoke alarm, we will see the Test record from the APP and it enters into silence mode. 9 minutes later automatically, or when you press the “TEST” button again until you hear one sound, it quits the silence mode.
2. When there is alarm caused by smoke, alarm history can be viewed for free.
3. The battery level is displayed as "Medium / High / Low". If the battery level is "low", please replace the battery as soon as possible.


Problem Summary:

- 1: When you can't connect the alarm, pay attention to the distance between the device, cell phone and router.
- 2: Networking WIFI router must be a 2.4G gateway, in order to connect to the APP network.


Connection stages:




Picture 1




Picture 2



Picture 3



Picture 4



Picture 5